MB 660 (SCBT5) MB Pro 1 | MB Pro 2 | Presence | BTD 800 USB

# Important safety instructions



- Read the instruction manual, safety guide, quick guide (as supplied) carefully and completely before using the product.
- Always include this safety guide when passing the product on to third parties.
- ▶ Do not use an obviously defective product.
- Only use the product in environments where wireless Bluetooth® transmission is permitted.
- Before putting the product into operation, please observe the respective country-specific regulations!

#### Preventing damage to health and accidents

Do not listen at high volume levels for long periods of time to prevent hearing damage.



- Always maintain a distance of at least 3.94" (10 cm) between the ear cups and the cardiac pacemaker or implanted defibrillator since the product generates permanent magnetic fields.
- Keep the product, accessories and packaging parts out of reach of children and pets to prevent accidents and choking hazards.
- Do not use the product in an environment that requires your special attention (e. g. in traffic).

## Preventing damage to the product and malfunctions

- Always keep the product dry and do not expose it to extreme temperatures (heater, extended exposure to sunlight, etc.) to avoid corrosion or deformation.
- Only use attachments/accessories/spare parts supplied or recommended by Sennheiser.
- Only clean the product with a soft, dry cloth.

#### Safety instructions for the Lithium-Polymer battery pack



#### **WARNING**

In extreme cases, abuse or misuse of Lithium-Polymer battery pack can lead to:

- explosion
- heat
- fire
- · smoke or gas



Only use rechargeable batteries recommended by Sennheiser and the appropriate chargers.



Do not expose to moisture.



Switch rechargeable battery-powered products off after use.



Only charge rechargeable batteries at ambient temperatures between 10 °C/50 °F and 40 °C/104 °F.



When not using rechargeable batteries for extended periods of time, charge them regularly (about every 3 months).



Do not mutilate or dismantle.



Do not heat above +60 °C/140 °F, e.g. do not expose to sunlight or throw into a fire.



Dispose of defective products with built-in rechargeable batteries at special collection points or return them to your specialist dealer.

#### Intended use/Liability

These products are accessories for mobile phones or any **Bluetooth** compliant device supporting profiles (e. g. "Hand Free Profile" - HFP) described in the Technical specifications for each product. They are intended for wireless communication via **Bluetooth** connection.

It is considered improper use when this product is used for any application not named in the associated product guides.

Sennheiser does not accept liability for damage arising from abuse or misuse of this product and its attachments/accessories.

Sennheiser is not liable for damages to USB devices that are not consistent with the USB specifications.

Sennheiser is not liable for damages resulting from the loss of connection due to flat or over aged rechargeable batteries or exceeding the **Bluetooth** transmission range.

MB 660 (SCBT5) | MB Pro 1 | MB Pro 2 | Presence | BTD 800 USB

## **Manufacturer Declarations**

### In compliance with the following requirements

• WEEE Directive (2012/19/EU)

Please dispose of this product by taking it to your local collection point or recycling center for such equipment. This will help to protect the environment in which we all live.

Battery Directive (2006/66/EC & 2013/56/EU)
The product's built-in rechargeable batteries can be recycled. In order to protect the environment, please dispose of defective products with their rechargeable batteries as special waste or return them to your



#### **CE Conformity**

specialist dealer.

- R&TTE Directive (1999/5/EC)
- RoHS Directive (2011/65/EU)

The CE Declaration of Conformity is available on our website at www.sennheiser.com/download, and search for product by name.



Sennheiser Communications A/S gives a warranty of 24 months on this product.

For the current warranty conditions, please visit our website at www.sennheiser.com or contact your Sennheiser partner.

#### Sennheiser product warranty FOR AUSTRALIA ONLY

Sennheiser's goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to other rights or remedies under law. Nothing in this warranty excludes, limits or modifies any liability of Sennheiser which is imposed by law, or limits or modifies any remedy available to the consumer which is granted by law.

To make a claim under this warranty, contact

Sennheiser Australia Pty Ltd,

Unit 3, 31 Gibbes Street Chatswood NSW 2067, AUSTRALIA

Phone: (02) 9910 6700,

email: service@sennheiser.com.au.

All expenses of claiming the warranty will be borne by the person making the claim.

The Sennheiser International Warranty is provided by Sennheiser Australia Pty Ltd (ABN 68 165 388 312), Unit 3, 31 Gibbes Street Chatswood NSW 2067 Australia.











