

Auto power on/off

MTK5580 & MTK5580P2

[1] Auto power on-off:

This monitor is able to switch on and off via the signal detection on the **last** used source input.

How to let the monitor switch on and off automatically via the signal detection:


Press home button on the RC, select “general settings”

Eco mode = “normal” (default it is on “low power standby”)

Switch on state = “on” (default = “last status”)

Advanced power management = “on” (default = “on”)

If Advanced power management is “off” the monitor will not switch off or on automatically via the input signal.



[2] Failover is **not** available.