
Setting the Time Zone and Country


When starting with the factory default settings (Example: First time to access, or after an initialization), you must configure the Time Zone and Country code*.
*Required only in Europe.

NOTE: To reset settings, click <Reset> before clicking <Apply>.

1 Open your web browser, then enter "http://192.168.0.1/" into the address bar.




- 2 Push the [ENTER] key.
 - The Login Authentication screen is displayed.
- 3 Enter "admin" into both input fields on the Login Authentication screen, and then click <OK>.




Only in Europe:

Select the appropriate Country code of use, and then click <Apply>.

(Management > Country)



Select the appropriate Time Zone, and then click <Apply>. (Management > Date and Time)



Dec. 2018 A7493W-4EX