

RADIATING CABLES

Installation Guide

Edition 6





Content

Radiating Cables Installation Edition 6

General instructions

- 4** Safety on site
- 5** Radiating Cable positioning in tunnels
- 6** Installation of EUCARAY® Radiating Cables
- 7** Orientation of slots for RMC Cables
- 8** Drilling and clamping
- 9** Mounting in tunnel
- 10** Installation recommendations

Installation instructions for clamps

- 12** SKH - Radiating Cables clamps - Wall or Ceiling mount of SKH
- 13** Wall or Ceiling mount of SKH with FSB
- 15** Installation instruction for clic clamp with Nylon plug and round base spacer
- 16** Installation instruction for clip hangers EUCH-xx-NH
- 17** Installation instruction for clip clamp with steel plug and steel spacer

Installation instructions for connectors

- 18** Connectors installation for Radiating Cables RC 400
- 19** Connectors installation for Radiating Cables 1/2"
- 20** Connectors installation for Radiating Cables 5/8"
- 21** Connectors installation for Radiating Cables 7/8"
- 22** Connectors installation for Radiating Cables 1-1/4"
- 23** Connectors installation for Radiating Cables 1-5/8"
- 24** Connectors installation for Radiating Cables 1-1/4" & 1-5/8" S-Type
- 26** Installation video

All information given is indicative only and not binding and can be subject to change without notice.

General instructions


Safety on site

Cordoning - off the working area

- Warning Signs
- Warning Cones
- Warning Lights
- Warning Tape






Keeping the access and emergency routes clear of

- Materials
- Tolls
- Vehicles






Fire precautions

- Easily inflammable materials should be ...
 - kept to a minimum
 - disposed of immediately if not necessary any longer
 - brought into the tunnel only in the amount required





Radiating Cable positioning in tunnels

 No radiating cable in these areas





Installation of EUCARAY® Radiating Cables


Recommended min. spacing of Radiating Cable to other cable or obstacles.



Recommended min. spacing for MiMo installation.



Orientating the cable to the receiver leads to best results.




Note: the clamp spacing and recommended distance to wall per cable is stated on the data sheet (example):

- **Recommended Clamp Spacing:**
m (ft) 1.0 (3.28)

- **Distance to Wall recommended / min.:**
mm (in) 80 - 180 (3.15 - 7.00) / 50 (1.96)

Orientation of slots for RMC cables

Apertures oriented towards area to be covered.
The slots are located 180° opposite to an embossed line on the jacket.




A= Recommended zone for RMC-cable

The slots are located 180° opposite to an embossed line on the jacket.


For LSC- and CMC-cables a cable orientation is not needed.

Drilling and clamping


Every 1 meter, the recommended hangers are non-metallic clic clamps or clamps without fire resistant belt.




Every 10 meters, the recommended hangers should be of **fire resistant type**. They can be clamps with metal anchor and fire resistant belt, or steel clamps.



Mounting in tunnel




Roll the cable carefully off the drum and lay it on the ground.




Lift the cable to the clamps avoiding kinks or damages.

Respect the bending radius.




Installation recommendations

Bending of RF-Cables



Expansion loops



Connection of two EUCARAY® radiating cables









For long runs of radiating cables, when the required cable length exceeds the length on a standard drum, radiating cables can be connected together.

In order to absorb cable extensions due to temperature changes, it is recommended to use a jumper cable which runs in a loop (ring) between the two sections of radiating cables.


We recommend for this purpose Eupen EC4-HF-S-100-Hilfex jumpers.

SKH – Radiating Cable clamps Wall or Ceiling mount of SKH






SKH – Radiating Cable clamps






Wall or Ceiling mount of SKH with FSB (recommended every 10 meters)



- A SKH - Strahlende Kabel Halter
- B FSB - Fire resistant band
- C Metal anchor Ø 6mm
- D IPL


FSB Fire Safety Band to be added to SKH every 10m





Installation instruction for clic clamp with Nylon plug and round base spacer

(recommended every 1 meter)



- A Nylon dowel 6 x 30 mm
- B Round base spacer RB80
- C Screw WS125 Ø 4,5 mm
- D Clic clamp

1

Drill a hole of 6 mm and insert the Nylon plug into the wall.



2

Tighten the screw.




3







Installation instruction for clip hangers **EUCH-xx-NH**

(recommended every 10 meters)




- A** Stainless steel plug M6 HPM6-SS
- B** Bolt with metric thread, stainless steel B6/90-SS (M6 x 90, hex socket head), with washer
- C** Round base spacer RB80
- D** Clip hanger EUCH-xx-NH
- E** Hammer
- F** Setting tool






Installation instruction for clip clamp with steel plug and steel spacer

(recommended every 1 meter)














- A Stainless steel plug M8 HPM8-SS
- B Stainless steel spacer SSP6/75/8
- C Flat nut M6 FN6
- D Clic clamp
- E Hammer
- F Setting tool






Installation instructions for connectors

Connectors installation for Radiating Cables RC 400













10 - for installations in harsh environments, the use of an optional heat-shrink is recommended.

Connectors installation for Radiating Cables 1/2"















	NF, 7-16F	NM	7-16M
	2 x 22 mm	2 x 22 mm & 19 mm	2 x 22 mm & 32 mm






Link to installation video on Youtube













Connectors installation for Radiating Cables 5/8"



Connectors installation for Radiating Cables 7/8"



	NF, 7-16F, 4.3-10F	NM	7-16M
	2 x 34 mm	2 x 34 mm 19 mm	2 x 34 mm 32 mm


















13 - for installations in harsh environments, the use of an optional heat-shrink is recommended.



Link to installation video on Youtube

Connectors installation for Radiating Cables 1 – 1/4"






















13 - for installations in harsh environments, the use of an optional heat-shrink is recommended.




Link to installation video
on Youtube












Connectors installation for Radiating Cables 1 – 5/8"











Link to installation video on Youtube

S-Type Connectors installation for Radiating Cables 1-1/4" & 1-5/8"

 43FR114S1 43FR158S1 716FR114S1 716FR158S1	 VASELINE	 Cable preparation tool F-114R-A F-158R-A
ø 63 mm  ø 5 mm  32 mm	 Cable preparation tool F-114R-B F-158R-B	
 Abrasive pad Metal-free Ultrafine		

1 	2  OR WEB	3  F-114R-A	4  19 ±1mm
5 	6 	7 	8 
9  ≥ 25 mm	10  VASELINE	11 	12 





Installation video

How to install connectors on EUPEN feeder cables



Installation videos can be found on the YouTube channel

www.youtube.com/@kabelwerkeupenag9930



Kabelwerk
EUPEN AG



Malmedyer Str. 9 - 4700 EUPEN - BELGIUM
Tel.: +32(0)87 59 70 00 e-mail: info@eupen.com
www.eupen.com ISO Certified Company