

Tactical Wireless

PTT AC

Operating distance: 2 meters

Reichweite: 2 Meter

PHONAK

English

User manual


The Tactical PTT AC is a handheld device. It is used to remotely activate the PTT (push to talk) feature of any 2-way radio.

The Tactical PTT AC must always be used in combination with a Phonak AC-branded receiver device (such as Cobra AC, profilo WL/LM AC, primero AC or Serenity DPC AC).

This model of Tactical PTT – or any other that is specifically 'AC' branded – is not backwards compatible. It is only usable in combination with other products that are marked 'AC'.


Operating distance

The Tactical PTT AC's operating range is a full 2 meters, giving the user a reliable communication link even if his/her arm is outstretched.




Battery insertion

To insert the battery (AAA, 1.5V) please slot a coin in the battery door opening, push down and turn left until reaching the "OPEN" position. Insert the battery with the "-" end first and close the compartment door by pressing down and turning to the right until the "ON" position is reached.



The push buttons are used for the following functions:



Identification mode

To program your system, turn on your radio. Once turned on, the program mode remains 'on' for 3 minutes. Please also check that the position of the battery opening of the Tactical PTT AC is in the "ON" position. To synchronize the Tactical PTT AC with the receiver, place the two devices close together and simultaneously push keys #2 and #3. You will hear 3 signal tones in the In-Ear-Receiver. This means the two devices are now paired and no other Tactical PTT AC will work with this system.

You will hear 3 signal tones in the In-Ear-Receiver. This means the two devices are now paired and no other Tactical PTT AC will work with this system.

You will hear 3 signal tones in the In-Ear-Receiver. This means the two devices are now paired and no other Tactical PTT AC will work with this system.

Push to talk (PTT)

To transmit speech, push and hold down key #1. In case of loss/damage/failure of the Tactical PTT AC, simply continue to use the receiver's integrated PTT function.

To transmit speech, push and hold down key #1. In case of loss/damage/failure of the Tactical PTT AC, simply continue to use the receiver's integrated PTT function.

Tone board

Briefly push key #2 or key #3 to generate a tone on the receiving radio device. (Each press generates a tone of the same loudness and length).

Briefly push key #2 or key #3 to generate a tone on the receiving radio device. (Each press generates a tone of the same loudness and length).

Briefly push key #2 or key #3 to generate a tone on the receiving radio device. (Each press generates a tone of the same loudness and length).

Mute function

Hold down key #2 or #3 for 3 seconds to mute the system. To reverse this mute function and return to normal volume, briefly press any key, or hold down key #2 or #3 for 3 seconds. (With the push of this button, its usual function will also be activated.)

Hold down key #2 or #3 for 3 seconds to mute the system. To reverse this mute function and return to normal volume, briefly press any key, or hold down key #2 or #3 for 3 seconds. (With the push of this button, its usual function will also be activated.)

Hold down key #2 or #3 for 3 seconds to mute the system. To reverse this mute function and return to normal volume, briefly press any key, or hold down key #2 or #3 for 3 seconds. (With the push of this button, its usual function will also be activated.)

Battery status

Simultaneously push keys #2 and #3 and hold for 3 seconds. If the resulting LED shows a constant light, the battery's charge is OK. A blinking light means the battery's strength is weak. To change the battery, follow the "battery insertion" instructions described above.

Simultaneously push keys #2 and #3 and hold for 3 seconds. If the resulting LED shows a constant light, the battery's charge is OK. A blinking light means the battery's strength is weak. To change the battery, follow the "battery insertion" instructions described above.

Simultaneously push keys #2 and #3 and hold for 3 seconds. If the resulting LED shows a constant light, the battery's charge is OK. A blinking light means the battery's strength is weak. To change the battery, follow the "battery insertion" instructions described above.

Simultaneously push keys #2 and #3 and hold for 3 seconds. If the resulting LED shows a constant light, the battery's charge is OK. A blinking light means the battery's strength is weak. To change the battery, follow the "battery insertion" instructions described above.

Troubleshooting

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

If no transmission is possible:


If no transmission is possible:

If no transmission is possible:

If no transmission is possible:

Batterie einsetzen

Um die Batterie (AAA, 1.5V) einzusetzen, drücken Sie mit einer Münze den Deckel des Batteriefaches leicht nach unten und drehen diesen nach links bis die «ON»-Stellung erreicht ist. Setzen Sie nun die Batterie mit dem «-» Pol nach Unten in das Fach ein. Um das Batteriefach zu schliessen drücken Sie den Batteriedeckel mit einer Münze wieder leicht nach unten und drehen ihn in die «ON» Stellung.



Die Tasten werden für folgende Funktionen verwendet:



Identifikations-Modus

Um Ihr System zu programmieren, schalten Sie das Funkgerät ein. Der Programmiermodus ist jetzt für genau 3 Minuten aktiv. Stellen Sie zudem sicher, dass bei der Tactical PTT AC die Stellung des Batteriedeckels auf «ON» ist. Damit die Tactical PTT AC vom Empfängerteil erkannt wird, müssen Sie die beiden Geräte dicht nebeneinander halten und die Tasten 2 und 3 gleichzeitig kurz betätigen. Wenn dieser Vorgang erfolgreich durchgeführt wurde, erhalten Sie als Bestätigung drei Signaltöne über den Im-Ohr-Empfänger. Die beiden Geräte sind nun aufeinander abgestimmt. Die HSG funktioniert nun ausschliesslich mit dieser einen Tactical PTT AC.

Drahtlose Sprechtaaste

Drücken Sie die Taste 1 solange, wie eine Übertragung (Sprechen) erfolgen soll. Im Falle eines Verlustes / einer Beschädigung / eines Defektes der Tactical PTT AC, ermöglicht die integrierte PTT eine Fortführung der laufenden Operation.

Tonboard

Drücken Sie kurz Taste 2 oder 3 um beim Funkempfänger einen Ton/Piep zu generieren. Jeder Tastendruck generiert einen Ton in identischer Lautstärke und Sendelänge.

Stummschaltung

Drücken Sie die Taste 2 oder 3 länger als drei Sekunden, um das System vollständig stumm zu schalten (Mute). Um die Mute Funktion wieder aufzuheben, genügt es irgend eine der Tasten kurz zu betätigen. Mit dem Tastendruck (Mute aufheben) wird gleichzeitig die entsprechende Funktion abgerufen.

Batterieanzeige

Drücken Sie Taste 2 und 3 gleichzeitig drei Sekunden lang, bis eine rote LED aufleuchtet.


Wenn die LED konstant leuchtet, ist die Batterie in Ordnung. Ein Blinken der LED bedeutet, dass die Batterie schwach ist. Um die Batterie auszuwechseln, befolgen Sie bitte der Anweisung «Batterie einsetzen» wie oben beschrieben.

Fehlersuche Keine Übertragung möglich:

- Überprüfen Sie ob das Empfängerteil auch mit «AC» markiert ist.
- Überprüfen Sie, ob das System stumm geschaltet wurde.
- Überprüfen Sie, ob die Tactical PTT AC und der Empfängerteil aufeinander abgestimmt sind (Identifikationsmodus)
- Überprüfen Sie die Batterie der drahtlosen PTT.

Das Gerät erfüllt Teil 15 der FCC-Richtlinien. Für den Betrieb dieses Geräts gelten folgende Voraussetzungen: (1) Dieses Gerät kann keine Störungen verursachen, und (2) dieses Gerät kann gestört werden, u. U. sogar in einem solchen Masse, dass es zu unerwünschten Betriebssituationen kommt.

Warnung: Änderungen an diesem Gerät, die nicht ausdrücklich durch Phonak Communications AG zugelassen wurden, können die FCC Zulassung für das Bedienen dieses Geräts ungültig machen.



Achtung: Verwenden Sie die Tactical PTT AC nicht in einem Krankenhaus oder in einem Flugzeug.


Dieses Gerät erfüllt die europäischen R&TTE-Richtlinien (2014/53/EU). Der vollständige Text der Konformitätserklärung kann auf der Webseite unter: <http://www.phonak-communications.com/de/zertifikate/> aufgerufen werden.

Different options to wear the Tactical wireless PTT AC / Verschiedene Möglichkeiten die Tactical wireless PTT AC zu montieren

Option A

Tactical Wireless PTT AC with CLIP /


Tactical Wireless PTT AC mit CLIP



Option B

Tactical Wireless PTT AC with Velcro band /

Tactical Wireless PTT AC mit Klettverschluss



Option C

Tactical Wireless PTT AC only with Velcro sticker /

Tactical Wireless PTT AC mit selbstklebendem Klettband



Phonak Communications AG
Herrenschwandweg 4,
CH-3280 Murten, Switzerland

www.phonak-communications.com