

Få TLK 100 på et nytt WiFi nett

In order to resolve quickly you can manually add a WiFi network to the device

1. You can put the TLK into maintenance mode, by pressing Power On + PTT + Ch- for 3 secs. A spanner shape will be displayed briefly.
2. Connect a USB cable to TLK and PC.
3. Go to Network and sharing center TCP/IP and change IP address on PC to 192.168.100.5 255.255.255.0 or choose DHCP (get automatically IP address)
4. Open browser and type 192.168.100.1



6. There should be a button to add WiFi network. Enter WiFi details. Click save and reboot



7. The TLK will reboot and connect via WiFi and download the settings/software.